



USER'S MANUAL

SLIDING GATE OPENER SL350 SERIES





Equipped with quick release keys for gear clutch
Remote control with 433MHz Rolling code
Soft stop function which treasures your gate
Adjustable Auto-close function

Content of the Kit:




Wiring Diagram:



Important Safety Advice:

1. Knowledge of the relevant electro-technical regulations is required.
2. Training in use and maintenance of safety equipments is necessary.
3. Professional assistance is required when some mechanism adjustment is needed.
4. Always lay mains and control cables separately.
5. Test every equipment before initial operation.
6. Make familiar with the use of the system before initial operation.
7. Unplug the mains before attempting to connect power cable to the system.

Measurements (mm)




Qualification of a properly designed sliding gate:

As a general rule, an automatically operated gate must be stronger and smoother than a manually operated gate. Since the gate is a major component of the system, great care and concern must be given to the gate design.



A poorly designed gate can damage a gate operator.

Check if the gate slides smoothly on the rail without binds or excessive resistance. The rail has to be level, so the gate will slide without resistance on it. The gate structure must be an in-line structure and has a balanced center of gravity.


Upper roller guides: The gate must be equipped with a set of roller guide with at least 2 rollers in one line.



Caution: A stopper on each end of the rail is required to bring the gate back to still condition and prevent the gate from getting off the rail.




Wheels: To keep the gate sliding smoothly, the shape and size of the wheel should suit the shape and size of the rail, so there will be no resistance coming from the friction.




1. Prepare a concrete block and drill four holes in the block to fit the metal base plate for the motor. Keep a proper distance between the edge of the plate and the tooth rack,
2. Pass the power cable through the big hole on the plate.
3. Adjust the screws and nuts to level the plate.

4. Adjust the position of the motor to make the tooth rack connect with the tooth cog wheel of the motor leaving 2-3mm vertical distance between tooth rack and cog wheel.

Keep a distance of about 2-3mm between tooth rack and the output cog wheel through out the full length of the rack




5. Secure the motor on the base plate by tighten the four screws.





Four screws to secure the motor.


6. Insert and turn the key counterclockwise and pull to release the motor clutch and move the gate to see if the gate slides well.




7. Fit the limit block to the tooth rack at the intended position, fix the limit block with the screws provided.




8. Lock up the clutch.
9. Make sure the power cable is disconnected from the mains and connect the three wires to the power socket in the system.





Functional diagram



Wiring with PCB:



Wiring of exterior manual buttons:



P1 / SET


Press P1 button for over 2 seconds to proceed the open/close learning of gate operating length. The system will learn where to stop softly according to the position of limit blocks.



P2 / RADIO

Press P2 button for over 2 seconds, the system will test the polarity of the motor. Please check if the gate opens first and then closes. In case the gate closes first then the wires of the motor have to be switched.

Indication LEDs



LD1



LD2



JP1




Jumper in: The upper buttons of the remote control are selected.
A for fully open, B for pedestrian's open.





Jumper out: The lower buttons of the remote control are selected.
C for fully open, D for pedestrian's open.




Wiring of the limit switch:



When the gate is supposed to be opened to the right hand side, please connect the wires of the limit switch as shown below.



When the gate is supposed to be opened to the left hand side, please connect the wires of the limit switch as shown below.



Quick Start

Connect the power cord, motor, photocells and warning light to the control box

Check the Polarity of motor

Switch on the control box and press P1/SET button for 2 sec.

LD1 flashes

The gate opens a bit, stops and closes fully.

Open / Close Learning

Press P1/SET button for 2 sec.

LD1 lights up, Learning mode entered

The gate opens a bit and then closes fully.

The gate opens fully

The gate closes fully

RF learning

Press P2/RADIO button for 2 sec.

LD2 lights up, RF Learning mode entered

LD2 blinks for 3 times, remote control learnt.

Press on any button on the remote control

learn another remote control or abort automatically.


Test the polarity of the motor:

To make sure that the motor rotates in right direction, please proceed this function prior to the Open / Close Learning.


Press "P2/RADIO" button on the PCB before the system finishes with 8 flashes of LD1 (green LED) right after the power connection. After releasing the "P2/RADIO" button, it will enter the test mode for the polarity of the motor as below:

Remove any obstacle could possibly block the gate.
Before the motor start, the warning light will blink.
The sequence of the learning process will be: "open--stop--close fully".

Check if the working directions are right as you need.
If not, please switch the wires of the motor connected on the terminal of the PCB.



P2




Open / Close Learning:

Please proceed this function before using this product, otherwise the system will drive the gates improperly. E.g.: The gate can't close or open completely.

To activate this function, press " P1/SET" button on the PCB for 2 seconds while the PCB is on. After releasing the "P1/SET" button, it will enter the open/close learning mode as below:

The system will close the gates first.
Remove any obstacle could possibly block the gate.
Before the motor start, the warning light will blink.
The sequence of the learning process will be:
"open-stop-close fully-open fully-close fully"



P1

NOTE:

The Open/Close Learning might not be done successfully due to the over-weight of the gates. Meanwhile, the Current Limit (VR4) needs to be increased a bit. Please refer to page 13 of this manual.


If any assistance is needed, please contact the technicians of our agent.

Remote Learning (activation of remote control for gate operation):

To activate the remote control service, please proceed the following steps:

A. RF gate learning: (for Open/Close the Gate)

1. Press and hold "P2/RADIO" button on the PCB until the LD2 (red LED) lights up, while the PCB is on. (now the learning mode is entered)
2. Press any button on the remote control, LD2 will now blink for 3 times (learning succeeded) or light off after 10 seconds without blinking (learning failed, please try again the whole process).
3. Please learn the next remote control right after the 3 blinks of LD2. If no blink followed, please repeat step 1 and 2, otherwise the unlearnt remote control won't be recognized by the system.




P2

Remote Control:



Use the 2 upper buttons (A, B) while the JP1 is in.
Use the 2 lower buttons (C, D) while the JP1 is out.



LD1

LD2

The remote control has 4 buttons on it, only two of them are necessary for the operation. User can connect the pins of JP1 for choosing A and B buttons, disconnect the JP1 for C and D buttons.

Operation with revolving commands (open, close and stop) by remote control:

When the VR2 is turned to the end of the CW direction, the system operates with revolving commands which no Auto-Close function will follow:

Button A or C: the first press will open the gate fully, next press to stop, next to close the gate, next to stop...and so on.

Button B or D: the first press will open the gate for pedestrian to pass, next press to stop, next to close the gate, next to stop...and so on.

When opening the gate:

1. Warning light will blink for 3 seconds, then gate opens.
2. If the gate hits something, the motor will reverse a bit and wait for next command.

When closing the gate:

1. The motor will close after the warning light blinks for 3 second.
2. If the gate hits something, the motor will reverse a bit and proceed Auto-Close function twice, in case any obstruction is still on the way. After that the system will halt any action and wait for next command.

Remark: The gate operation works properly only after successful Opening/Closing Learning.

Photocell triggered during the rotation of the motor:

1. While opening, the gate will still go on with opening.
2. While closing, the gate will open fully and ready for Auto-Close Function.
3. During Auto-Close Function, the gate will stand still upon triggered photocell.
The gate will close as soon as the photocell resumed.

Auto close:

SL350 will close the gate automatically after the gate has been opened for a certain period of time as set by turning the VR2 adjustment on the PCB (0~90sec).

Please note: If the VR2 is turned to the stop point of the adjustment in the CW direction, NO Auto-Close function will proceed. (Operation with revolving commands (open, close and stop) by remote control on page 10)

Clear RF memory:


Press "P2/RADIO" button on the PCB until the LD2 flashes, let go the button and press the button again until the LD2 flashes 6 times at a faster speed. RF memory is cleared.

Quick release:

The SL350 series are equipped with a clutch mechanism inside the motor to provide user with an alternative to open the gate manual during power failure. Please unlock the clutch only when the motor is static.

Sleeping mode during Battery low:

The SL350 system will be forced to enter the sleeping mode when the battery is low. During the sleeping mode, all functional features will be seized until power recovery.



1 Set of Photocell

Operation of Photocell:

Select a proper installing location, where the IR transmitter and receiver along the same line and at the same height. Connect the wires of the photocell to the operator's PCB as wiring diagram above.


Power on the system, try and see if it works properly by obstructing the IR between the transmitter and receiver for some times. The relay in the receiver should respond accordingly while LED switches ON and OFF.

With photocell well installed, while it's triggered during sliding open, the system will ignore the IR obstruction and still go on with opening. While it's triggered during sliding close, the gate will reverse a bit, then stop and wait for next command.


Troubleshooting:

| Problem | Probable Cause | Correction |
|---|--|--|
| No response when open command is given. (neither the gate moves nor the motor starts) | No Power | Plug the power cable to the system |
| | Emergency shut-down activated | Make a jumper between the STP and earth on the terminal bus. (page 5) |
| | Fuse burnt | Replace with a new fuse |
| | Defect power cable to motor | Replace with proper power cable. |
| | Obstruction of Photocell beam | Make sure the Photocell well aligned and not obstructed. |
| | Button jammed | Make sure the buttons on the remote control and interphone are functioning well. |
| | Wrong wiring on the limit switches or PCB | Check out the wiring according to page 5~7 |
| The motor starts when it receives command, but the gate stands still. | Gate slides badly | Make sure the roller guides is well lubricated and unlock the clutch to slide the gate manually ato see if it slides smoothly. |
| | Clutch is open | Lock the clutch up |
| | Insufficient motor force | Turn the VR4 CW a bit and try again |
| The gate closes while it should open. | Wrong connection on the terminal for motor | Check out the wiring according to page 5~7 |
| The gate opens but never close | The system is in the mode of revolving command | Make sure the VR2 is not at the maximum point |
| | Bad alignment of Photocell | Check alignment and reassure the wiring of the photocell. |

Factory settings of Adjustments:



Please note: The adjustment has a maximum rotation of 1 turn, beginning from the CCW end to the CW end. Please do not force the adjustment past the stop points.



Adjustment on motor speed



CW=speed up
CCW=slow down



Auto Close Timer


CW=increase waiting time CCW=decrease waiting time

This timer works also as a switch for revolving command mode, when it's turned to the end of CW direction. It makes the system close the Auto Close function and do Open-stop-close-stop-open... in turns when you press the remote control.



Obstacle Detection

CW=increase tolerance time to react while the gate runs into an obstacle
CCW=decrease tolerance time to react while the gate runs into an obstacle



Sensibility

CW= DECREASE sensibility to the resistance against sliding (for heavy gate or badly maintained gate)
CCW= Increase sensibility to the resistance against sliding (for gate which slides smoothly)

Specifications :

| | |
|--------------------------------------|---|
| Model | SL350 |
| Power Supply | 110 / 230V AC + 10% 60 / 50Hz |
| Power for Motor | 12 / 24 VDC |
| Maximum Gate Weight | 350KGS (770Lbs) Max. |
| Maximum Gate Width | Not important |
| Length of Tooth Rails | 3.1M (10Feet) with 6 tooth racks |
| Opening Speed | 9 meters per minute |
| Protection Rating | IP 44 |
| Thermal Overload Protection | 135°C |
| Duty Cycle | 20% |
| Operation Temperature | -20°C / +50°C |
| Overload Protection | Adjustable Current Detection |
| Backup Recharging Battery Foundation | Yes (Not Including Battery 12V,7AH) |
| Auto Close Function | Adjustable timer (0~90sec) |
| Extension Terminal | Warning Light / Photocell / Back-up Battery |
| RF Carriage | 433.92 MHz w/ Rolling Codes |
| Control Range | Approx. 30~50 Meters |